

IVE-W530BT Firmware Update



ALPINE ELECTRONICS GmbH
Wilhelm-Wagenfeld-Straße 1-3,
80807 München, Germany
Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K., LTD.
Alpine House
Fletchamstead Highway, Coventry CV4 9TW, U.K.
Phone 0870-33 33 763

ALPINE ELECTRONICS FRANCE S.A.R.L.
(RCS PONTOISE B 338 101 280)
98, Rue de la Belle Etoile, Z.I. Paris Nord II,
B.P. 50016, 95945 Roissy Charles De Gaulle
Cedex, France
Phone 01-48638989

ALPINE ITALIA S.p.A.
Viale C. Colombo 8, 20090 Trezzano
Sul Naviglio (MI), Italy
Phone 02-484781

ALPINE ELECTRONICS DE ESPAÑA, S.A.
Portal de Gamarra 36, Pabellón, Pabellón, 32
01013 Vitoria (Alava)-APDO 133, Spain
Phone 945-283588

Introduction

This guidebook describes the procedure for updating the IVE-W530BT software.

Improvements

iPod music playback via USB connection with iPhone 5

Warning




WARNING - ACC OFF, removal of power, or unplugging of the USB stick during the update process will damage your device! Make sure you have a stable power supply!

Requirements


- USB stick
- PC with zip program

Preparation step 1: Format the USB stick

1. Plug in the USB stick.





2. Right click the USB drive and select “Format...”




3. Adjust the format settings:
- File System: Fat32 (Default)
 - Make sure to uncheck "Quick Format"

4. Before clicking OK, make sure that you have selected the correct drive




WARNING - The selected drive will be erased completely

5. The system formats the USB Stick.
This can take up to 10 minutes.




6. After formatting has finished
Push OK




Preparation step 2: Unpack the download


1. Right click the Update package




2. Select “**Extract files...**” to choose the advanced settings




3. Select your USB drive.



4. After unpacking, the USB stick contains one folder, with one file



5. Make sure to “remove the USB Stick safely” before unplugging it



6. A message is displayed once it is safe to remove the USB stick



Updating the IVE-W530BT

1. Turn on ACC and push the “**Source**” button to switch on the unit



2. Once the unit is booted, push “**Source**” again



3. Select “**USB**”



4. Connect the USB stick. “**Searching**” is displayed.




5. The update starts automatically. **“Update”** will be displayed on the screen.



6. The update screen displays the old and the new version as well as progress information.



7. At first the update is read from the USB stick. A progress bar is displayed on the last line



8. Then the data is written to the FLASH



Note: Even though the update is read from a USB media, “Reading from DISC” is displayed.

9. After the flashing has finished, the screen is black



10. Then „End“ is displayed



WARNING - ACC OFF, removal of power, or unplugging of the USB stick during this process will damage your device! Don't push any button. The update is fully automatic.

11. Finally, if “End” is displayed, quickly push the source button.



Note: This screen is displayed for approximately 5 seconds before the update is restarting automatically

12. If you did not push the button within 5 seconds, the update starts again, as shown below.



WARNING - In this case DO NOT interrupt the 2nd, 3rd etc update. Wait, and then go to STEP 11. The additional update will not harm the unit.

13. After pushing the source button within 5 seconds the source selection screen will be displayed.



14. Now turn OFF ACC and disconnect the USB stick. After waiting 10 seconds, turn on ACC again. Your iPhone 5 will now be recognized.

