

# **Mobile Media Solutions**

# INE-S900R Software Upgrade

Service Pack 2





#### ALPINE ELECTRONICS GmbH

Wilhelm-Wagenfeld-Straße 1-3, 80807 München, Germany Phone 089-32 42 640

#### ALPINE ITALIA S.p.A.

Viale C. Colombo 8, 20090 Trezzano Sul Naviglio (MI), Italy Phone 02-484781

#### ALPINE ELECTRONICS OF U.K., LTD.

Alpine House Fletchamstead Highway, Coventry CV4 9TW, U.K. Phone 0870-33 33 763

#### ALPINE ELECTRONICS DE ESPAÑA, S.A.

Portal de Gamarra 36, Pabellón, Pabellón, 32 01013 Vitoria (Alava)-APDO 133, Spain Phone 945-283588

#### ALPINE ELECTRONICS FRANCE S.A.R.L.

(RCS PONTOISE B 338 101 280) 98, Rue de la Belle Etoile, Z.I. Paris Nord II, B.P 50016, 95945 Roissy Charles De Gaulle Cedex, France Phone 01-48638989

### Introduction

This guidebook describes the procedure for updating the INE-S900R software.

### Requirements

- High Speed Internet connection
- PC including a CD writer
- Empty CD-Rom (2 pieces)

## Software Improvements

- USB video playback
- Video playback on side screen
- USB audio file management tree structure on audio search list
- SCDB with directional data encryption if the Map Version of your device is 1.00, the pre-installed SCDB data will have to be updated



- · Graphic User Interface change for postcode search
- · DVD mechanism firmware update
- Navigation application software improvements

### Software Upgrade for INE-S900R

- Download the file "INE-S900R\_Service-Pack-2.zip" to your PC and extract it. Insert an empty CD-R (CD-R 01).
- 2. Open your CD writer program. Go to "Copy Mode" and select "Burn Image". Browse for the file "01 DVD Drive Software", add it and burn the CD-R (CD-R 01).
- 3. Insert an empty CD-R (CD-R 02). Open your CD writer program. Go to "Copy Mode" and select "Burn Image". Browse for the file "02 Program Update", add it and burn the CD-R (CD-R 02).
- 4. Power on INE-S900R and insert the CD-R 01.
- 5. The update process will start. Confirm by clicking "Yes".



Note: Do NOT switch off ACC and do NOT eject the CD-R until the Update process is finished. The system reboots automatically after approximately 5 minutes (CD-R 01) and after 10 minutes (CD-R 02).

Repeat with step 4. using CD-R 02.

### **Version Information**